

Interfacing the 8051 with 2-wire Serial EEPROMs

INTERFACING MICROCHIP SERIAL EEPROMS TO THE INTEL 8051 FAMILY OF MICROCONTROLLERS

Many designers today are implementing embedded systems that require low cost non-volatile memory. Microchip has addressed this need with a full line of serial EEPROMs, in a variety of memory configurations, using the industry-standard 2 or 3-wire communication protocols. The theory and application of these protocols are addressed in detail in Microchip's application note AN536.

Microchip recognizes that its broad customer base uses a variety of micro-controllers; many firmware related questions have been asked concerning interfacing the 8051 family and its derivatives.

The purpose of this app note is to provide assembly language examples of 8051 code for the various serial EEPROMs available from Microchip. These routines are intended to provide the basic operating kernels for storing data to or retrieving data from a serial EEPROM.

All of the routines in this application note are available, as source code, for downloading from Microchip's worldwide website at www.microchip.com. The file to download is 00614.zip.

This app note covers all of Microchip's 2-wire serial devices. Note that some devices have features not supported in others, and therefore, some sections of the code presented here may not be applicable to a particular part. We have attempted to label those special sections to minimize confusion.


The code includes a simple loop-type shell to enable it to be executed (with an emulator) without the user having to write any other routines. The various address and data pointers must be set to the desired values by hand, before each execution cycle.

TIMING DATA

Clock and data timing is accomplished by software. There are two sets of timing specifications: 100 kHz and 400 kHz. Assuming a 12 MHz 8051 clock, extra NOP's have been added to slow timing down to 100 kHz. See Note 1 in the listing. If a 16 MHz clock is used, additional NOP's are required for 100 kHz operation. See Note 2 in the listing. For 400 kHz operation, the NOP's labelled Note 1 or Note 2 are not needed. If not needed the NOP's may be left out.

Below is the connection diagram used for this app note. Do not forget the pull-up resistor!

WIRING DIAGRAM



Please check the Microchip's website for the latest version of the source code @ www.microchip.com

APPENDIX A: SOURCE CODE

```
1  $MOD51
2  ;REGISTER ASSIGNMENTS
3  ;
4  ;R1 DATA OR DATA POINTER
5  ;R2 LOOP COUNTER REGISTER
6  ;R3 ADDRESS, HI BYTE
7  ;R4 ADDRESS, LOW BYTE
8  ;R5
9  ;R6 BYTE COUNT FOR PAGE OPERATIONS
10
11 ;PIN ASSIGNMENTS:
12 ;Port 1 bit 0 is data
13 ;Port 1 bit 1 is clock
14 ;
15 ;These routines assume chip address = 0
16 ;
17 ;The oscillator frequency assumed for this app note is 12 MHz
18 ;
19 ;These routines use software timing loops. They may have to be
20 ;adjusted if a different oscillator frequency is used.
21 ;
22 ;NOTE 1 These NOP's added for timing delays on 'C' parts, OR 'LC' parts
23 ;   where Vcc < 4.5V and the oscillator frequency is 12 MHz.
24 ;   This allows a bit rate of 100kHz.
25 ;NOTE 2 Use these NOP's with a 16MHz oscillator and 100kHz bit rate.
26 ;   For 400kHz bit rate, the NOP's in Note 1 and Note 2 are not req'd.
27 ;
28 ;The EEPROM will be busy after a write cycle is initiated
29 ;for up to 10mS per page (or per byte if a byte write). This app note
30 ;assumes the user will delay the appropriate time after write, or check
31 ;for Busy status. A subroutine is provided to check the Busy Status.
32 ;
33 ;RAM DEFINITIONS
34 DSEG
---- 35 ORG          30H
0030 36 BYTSTR:     DS      20H          ;STORAGE FOR READ DATA
0030 37 ;
38 ;CONSTANTS -- REDEFINE AS NECESSARY
39 ;
00A0 40 WTCMD      EQU     10100000B    ;WRITE DATA COMMAND Note 3
00A1 41 RDCMD      EQU     10100001B    ;READ DATA COMMAND Note 3
0040 42 RDEND      EQU     01000000B    ;READ HIGH-ENDURANCE BLOCK NUMBER COMMAND
0000 43 ADDRH      EQU     0
0000 44 ADDRRL     EQU     0
0055 45 DTA        EQU     55H
0008 46 BYTCNTEQU  8
47 ;
48 ;Note 3 Some chip or byte address bits are embedded in the control byte.
49 ;Refer to the data sheet for exact configuration, which varies from part
50 ;to part.
51 ;
52 ; *****
53 ; This section contains test loop routines. They form a simple operating
54 ; shell to allow the 2-wire interface code to be tested in a stand-alone
55 ; mode. Using an emulator, change "NONE" to one of the four listed
56 ; routines to test that function. The address and data constants can
57 ; also be set as desired.
58 ; If using a 32Kbit or higher density serial EEPROM, change the called
59 ; routines by adding 'L' to the end of the name. This is required
60 ; because these parts use TWO address bytes. The 'L' routines send out
61 ; the extra address byte.
62 ; *****
```

```

----          63 CSEG
0000          64 ORG          0
0000 020003   65 JMP          START
0003 7590FF   66 START:    MOV     P1,#0FFH      ;INIT PORT1
0006 12000B   67 CALL     NONE                    ;TEST LOOP INSERT PROPER ADDRESS HERE
0009 80F8     68 JMP          START
          69
000B 22      70 NONE:    RET
          71 ;*
          72 ;* WRITE ONE BYTE TO EEPROM
          73 ;* The Address Pointer is the address in the EEPROM.  The byte to be sent
          74 ;* to the EEPROM is stored in the constant 'DTA'
          75 ;*
000C 7B00    76 TESTWR:  MOV     R3,#ADDRH      ;LOAD ADDRESS POINTER FOR HIGH DENSITY ONLY
000E 7C00    77          MOV     R4,#ADDRL      ;LOAD ADDRESS POINTER FOR ALL DEVICES
0010 7955    78          MOV     R1,#DTA        ;LOAD DATA BYTE
0012 120037  79          CALL   BYTEW          ;CALL PAGE WRITE ROUTINE
0015 22      80          RET
          81
          82 ;*
          83 ;* WRITE A BLOCK OF DATA TO EEPROM
          84 ;* The address pointer is the address in EEPROM where data will start.
          85 ;* The byte pointer is the starting address of RAM containing the block
          86 ;* of data to be sent. The byte count indicates how many bytes to send to
          87 ;* the EEPROM. The number of bytes that can be sent before a STOP command
          88 ;* is issued is dependent on EEPROM type. Refer to the data book for
          89 ;* specific values.
          90 ;*
0016 7B00    91 BLKWR:   MOV     R3,#ADDRH      ;LOAD ADDRESS POINTER FOR HIGH DENSITY ONLY
0018 7C00    92          MOV     R4,#ADDRL      ;LOAD ADDRESS POINTER FOR ALL DEVICES
001A 7930    93          MOV     R1,#BYTSTR     ;LOAD BYTE POINTER
001C 7E08    94          MOV     R6,#BYTCNT     ;LOAD BYTE COUNT
001E 120048  95          CALL   PAGEW          ;CALL PAGE WRITE ROUTINE
0021 22      96          RET
          97
          98 ;*
          99 ;* READ ONE BYTE FROM EEPROM
         100 ;* The address pointer is the address of the desired byte in EEPROM.
         101 ;* The byte will be returned in R1.
         102 ;*
0022 7B00    103 TESTRD:  MOV     R3,#ADDRH      ;LOAD ADDRESS POINTER FOR HIGH DENSITY ONLY
0024 7C00    104          MOV     R4,#ADDRL      ;LOAD ADDRESS POINTER FOR ALL DEVICES
0026 120082  105          CALL   BYTERD         ;CALL BYTE READ ROUTINE.
0029 F9      106          MOV     R1,A           ;SAVE THE BYTE
002A 22      107          RET
          108
          109 ;*
         110 ;* READ A BLOCK FROM EEPROM
         111 ;* The address pointer is the starting address of the desired data block
         112 ;* in EEPROM. The data pointer is the starting address in RAM where data
         113 ;* will be stored. The byte count indicates how many bytes should be read
         114 ;* The entire EEPROM may be read with one READ command this way.
         115 ;*
002B 7B00    116 BLOKRD:  MOV     R3,#ADDRH      ;LOAD ADDR POINTER FOR HIGH DENSITY ONLY
002D 7C00    117          MOV     R4,#ADDRL      ;LOAD ADDRESS POINTER FOR ALL DEVICES
002F 7930    118          MOV     R1,#BYTSTR     ;LOAD DATA POINTER
0031 7E08    119          MOV     R6,#BYTCNT     ;LOAD BYTE COUNT
0033 12005C  120          CALL   BLKRD          ;CALL BLOCK READ ROUTINE
0036 22      121          RET
          122
         123 ;* END OF TEST LOOP
         124 ;*****
         125
         126
         127 ;*****
         128 ; This routine writes a byte of data to EEPROM

```

AN614

```
129 ; The EEPROM address is assumed to be in R4. See NOTE 3
130 ; The DATA to be written is assumed to be in R1
131 ;*****
0037 74A0 132 BYTEW:    MOV    A,#WTCMD    ;LOAD WRITE COMMAND
0039 12012F 133          CALL    OUTS        ;SEND IT
003C EC 134          MOV    A,R4        ;GET BYTE ADDRESS
003D 120167 135          CALL    OUT        ;SEND IT
0040 E9 136          MOV    A,R1        ;GET DATA
0041 120167 137          CALL    OUT        ;SEND IT
0044 1201A6 138          CALL    STOP       ;SEND STOP CONDITION
0047 22 139          RET
140
141 ;*****
142 ; THIS ROUTINE WRITES A PAGE OF DATA TO EEPROM
143 ; The EEPROM start address is assumed to be in R4. See NOTE 3
144 ; The DATA pointer is in R1
145 ; The BYTE count is in R6
146 ; The number of bytes that can be transferred depends upon the
147 ; EEPROM used
148 ;*****
0048 74A0 149 PAGEW:    MOV    A,#WTCMD    ;LOAD WRITE COMMAND
004A 12012F 150          CALL    OUTS        ;SEND IT
004D EC 151          MOV    A,R4        ;GET LOW BYTE ADDRESS
004E 120167 152          CALL    OUT        ;SEND IT
0051 E7 153 BTLP:    MOV    A,@R1      ;GET DATA
0052 120167 154          CALL    OUT        ;SEND IT
0055 09 155          INC    R1          ;INCREMENT DATA POINTER
0056 DEF9 156          DJNZ   R6,BTLP     ;LOOP TILL DONE
0058 1201A6 157          CALL    STOP       ;SEND STOP CONDITION
005B 22 158          RET
159
160
161 ;*****
162 ; THIS ROUTINE READS A BLOCK OF DATA FROM EEPROM AT A SPECIFIED ADDRESS
163 ; EEPROM address in R4. See NOTE 3.
164 ; Stores data at RAM location pointed to by R1
165 ; Byte count specified in R6. May be 1 to 256 bytes
166 ;*****
005C 74A0 167 BLKRD:    MOV    A,#WTCMD    ;LOAD WRITE COMMAND TO SEND ADDRESS
005E 12012F 168          CALL    OUTS        ;SEND IT
0061 EC 169          MOV    A,R4        ;GET LOW BYTE ADDRESS
0062 120167 170          CALL    OUT        ;SEND IT
0065 74A1 171          MOV    A,#RDCMD     ;LOAD READ COMMAND
0067 12012F 172          CALL    OUTS        ;SEND IT
006A 12018D 173 BRDLP:    CALL    IN          ;READ DATA
006D F7 174          MOV    @R1,a        ;STORE DATA
006E 09 175          INC    R1          ;INCREMENT DATA POINTER
006F DE04 176          DJNZ   R6,AKLP     ;DECREMENT LOOP COUNTER
0071 1201A6 177          CALL    STOP       ;IF DONE, ISSUE STOP CONDITION
0074 22 178          RET          ;DONE, EXIT ROUTINE
179
0075 C290 180 AKLP:    CLR    P1.0          ;NOT DONE, ISSUE ACK
0077 D291 181          SETB   P1.1
0079 00 182          NOP
007A 00 183          NOP
007B 00 184          NOP
007C 00 185          NOP          ;NOTE 2
007D 00 186          NOP
007E C291 187          CLR    P1.1
0080 80E8 188          JMP    BRDLP       ;CONTINUE WITH READS
189
190 ;*****
191 ; THIS ROUTINE READS A BYTE OF DATA FROM THE EEPROM
192 ; The EEPROM address is in R4. See Note 3
193 ; Returns the data byte in R1
194 ;*****
```

```

0082 74A0    195 BYTERD:    MOV     A,#WTCMD      ;LOAD WRITE COMMAND TO SEND ADDRESS
0084 12012F  196           CALL    OUTS          ;SEND IT
0087 EC      197           MOV     A,R4          ;GET LOW BYTE ADDRESS
0088 120167  198           CALL    OUT           ;SEND IT
008B 12008F  199           CALL    CREAD        ;GET DATA BYTE
008E 22      200           RET
201
202 ;*****
203 ; THIS ROUTINE READS A BYTE OF DATA FROM EEPROM
204 ; From EEPROM current address pointer.
205 ; Returns the data byte in R1
206 ;*****
008F 74A1    207 CREAD:      MOV     A,#RDCMD      ;LOAD READ COMMAND
0091 12012F  208           CALL    OUTS          ;SEND IT
0094 12018D  209           CALL    IN           ;READ DATA
0097 F9      210           MOV     R1,A         ;STORE DATA
0098 1201A6  211           CALL    STOP         ;SEND STOP CONDITION
009B 22      212           RET
213
214 ;*****
215 ; The next four routines are used with the the 24xx32 or 24xx65 only.
216 ; These parts require two address bytes, and these routines send the
217 ; second byte out. Other than this, these routines are the same as the
218 ; previous four.
219 ;*****
220 ; THIS ROUTINE READ A BLOCK OF DATA FROM EEPROM AT A SPECIFIED ADDRESS
221 ; This routine is for the 24LC32 or 24LC65.
222 ; EEPROM address in R3:R4.
223 ; Stores data at RAM locatoin pointed to by R1
224 ; Byte count specified in R6. May be 1 to 256 bytes
225 ;*****
009C 74A0    226 BLKRDL:    MOV     A,#WTCMD      ;LOAD WRITE COMMAND TO SEND ADDRESS
009E 12012F  227           CALL    OUTS          ;SEND IT
00A1 EB      228           MOV     A,R3          ;GET HI BYTE ADDRESS
00A2 120167  229           CALL    OUT           ;SEND IT
00A5 EC      230           MOV     A,R4          ;GET LOW BYTE ADDRESS
00A6 120167  231           CALL    OUT           ;SEND IT
00A9 74A1    232           MOV     A,#RDCMD      ;LOAD READ COMMAND
00AB 12012F  233           CALL    OUTS          ;SEND IT
00AE 80BA    234           JMP     BRDLP         ;CONTINUE WITH DATA READ
235
236 ;*****
237 ; This routine writes a byte of data to EEPROM
238 ; This routine is for the 24LC32 or 24LC65
239 ; The EEPROM address is assumed to be in R3:R4
240 ; The DATA to be written is assumed to be in R1
241 ;*****
00B0 74A0    242 BYTEWL:    MOV     A,#WTCMD      ;LOAD WRITE COMMAND
00B2 12012F  243           CALL    OUTS          ;SEND IT
00B5 EB      244           MOV     A,R3          ;GET HI BYTE ADDRESS
00B6 120167  245           CALL    OUT           ;SEND IT
00B9 EC      246           MOV     A,R4          ;GET LOW BYTE ADDRESS
00BA 120167  247           CALL    OUT           ;SEND IT
00BD E9      248           MOV     A,R1          ;GET DATA
00BE 120167  249           CALL    OUT           ;SEND IT
00C1 1201A6  250           CALL    STOP         ;SEND STOP CONDITION
00C4 22      251           RET
252
253 ;*****
254 ; THIS ROUTINE WRITES A PAGE OF DATA TO EEPROM
255 ; This routine is for the 24LC32 or 24LC65
256 ; The EEPROM start address is assumed to be in R3:R4
257 ; The DATA pointer is in R1
258 ; The BYTE count is in R6
259 ; The number of bytes that can be transfered depends on the
260 ; EEPROM in use
261 ;*****

```

AN614

```
00C5 74A0 262 PAGEWL:  MOV    A,#WTCMD    ;LOAD WRITE COMMAND
00C7 12012F 263      CALL   OUTS      ;SEND IT
00CA EB 264      MOV    A,R3      ;GET HIYTE ADDRESS
00CB 120167 265      CALL   OUT        ;SEND IT
00CE EC 266      MOV    A,R4      ;GET LOW BYTE ADDRESS
00CF 120167 267      CALL   OUT        ;SEND IT
00D2 E7 268 BTLPL:  MOV    A,@R1     ;GET DATA
00D3 120167 269      CALL   OUT        ;SEND IT
00D6 09 270      INC    R1        ;INCREMENT DATA POINTER
00D7 DEF9 271      DJNZ  R6,BTLPL   ;LOOP TILL DONE
00D9 1201A6 272      CALL   STOP      ;SEND STOP CONDITION
00DC 22 273      RET
274
275 ;*****
276 ; THIS ROUTINE READS A BYTE OF DATA FROM THE EEPROM
277 ; This routine is for the 24CL32 or 24LC65
278 ; The EEPROM address is in R3:R4
279 ; Returns the data byte in R1
280 ;*****
00DD 281 BYTERDL:
00DD 74A0 282      MOV    A,#WTCMD    ;LOAD WRITE COMMAND TO SEND ADDRESS
00DF 12012F 283      CALL   OUTS      ;SEND IT
00E2 EB 284      MOV    A,R3      ;GET HI BYTE ADDRESS
00E3 120167 285      CALL   OUT        ;SEND IT
00E6 EC 286      MOV    A,R4      ;GET LOW BYTE ADDRESS
00E7 120167 287      CALL   OUT        ;SEND IT
00EA 118F 288      CALL   CREAD     ;GET DATA BYTE
00EC 22 289      RET
290 ;
291 ; SUBROUTINES
292 ;
293 ;*****
294 ; This routine test for WRITE DONE condition
295 ; by testing for an ACK.
296 ; This routine can be run as soon as a STOP condition
297 ; has been generated after the last data byte has been sent
298 ; to the EEPROM. The routine loops until an ACK is received from
299 ; the EEPROM. No ACK will be received until the EEPROM is done with
300 ; the write operation.
301 ;*****
00ED 74A0 302 ACKTST:  MOV    A,#WTCMD    ;LOAD WRITE COMMAND TO SEND ADDRESS
00EF 7A08 303      MOV    R2,#8      ;LOOP COUNT -- EQUAL TO BIT COUNT
00F1 C290 304      CLR    P1.0      ;START CONDITION -- DATA = 0
00F3 00 305      NOP
00F4 00 306      NOP
00F5 00 307      NOP
00F6 00 308      NOP ;NOTE 2
00F7 00 309      NOP
00F8 C291 310      CLR    P1.1      ;CLOCK = 0
00FA 33 311 AKTLP:  RLC    A          ;SHIFT BIT
00FB 5005 312      JNC    AKTLS
00FD D290 313      SETB  P1.0      ;DATA = 1
00FF 020104 314      JMP    AKTL1     ;CONTINUE
0102 C290 315 AKTLS:  CLR    P1.0      ;DATA = 0
0104 D291 316 AKTL1:  SETB  P1.1      ;CLOCK HI
0106 00 317      NOP ;NOTE 1
0107 00 318      NOP
0108 00 319      NOP
0109 00 320      NOP ;NOTE 2
010A 00 321      NOP
010B C291 322      CLR    P1.1      ;CLOCK LOW
010D DAEB 323      DJNZ  R2,AKTLP   ;DECREMENT COUNTER
010F D290 324      SETB  P1.0      ;TURN PIN INTO INPUT
0111 00 325      NOP ;NOTE 1
0112 00 326      NOP ;NOTE 2
0113 D291 327      SETB  P1.1      ;CLOCK ACK
```

```

0115 00      328      NOP                      ;NOTE 1
0116 00      329      NOP
0117 00      330      NOP
0118 00      331      NOP                      ;NOTE 2
0119 00      332      NOP
011A 309002  333      JNB      P1.0,EXIT        ;EXIT IF ACK (WRITE DONE)
011D 80CE    334      JMP      ACKTST          ;START OVER
011F C291    335 EXIT:  CLR      P1.1          ;CLOCK LOW
0121 C290    336      CLR      P1.0          ;DATA LOW
0123 00      337      NOP                      ;NOTE 1
0124 00      338      NOP
0125 00      339      NOP
0126 00      340      NOP                      ;NOTE 2
0127 00      341      NOP
0128 D291    342      SETB     P1.1          ;CLOCK HIGH
012A 00      343      NOP
012B 00      344      NOP
012C D290    345      SETB     P1.0          ;STOP CONDITION
012E 22      346      RET
347
349
350 ;*****
351 ; THIS ROUTINE SENDS OUT CONTENTS OF THE ACCUMULATOR
352 ; to the EEPROM and includes START condition. Refer to the data sheets
353 ; for discussion of START and STOP conditions.
354 ;*****
355
012F 7A08    356 OUTS:  MOV      R2,#8          ;LOOP COUNT -- EQUAL TO BIT COUNT
0131 D290    357      SETB     P1.0          ;INSURE DATA IS HI
0133 D291    358      SETB     P1.1          ;INSURE CLOCK IS HI
0135 00      359      NOP                      ;NOTE 1
0136 00      360      NOP
0137 00      361      NOP
0138 00      362      NOP                      ;NOTE 2
0139 00      363      NOP
013A C290    364      CLR      P1.0          ;START CONDITION -- DATA = 0
013C 00      365      NOP                      ;NOTE 1
013D 00      366      NOP
013E 00      367      NOP
013F 00      368      NOP                      ;NOTE 2
0140 00      369      NOP
0141 C291    370      CLR      P1.1          ;CLOCK = 0
0143 33      371 OTSLP: RLC      A            ;SHIFT BIT
0144 5005    372      JNC      BITLS
0146 D290    373      SETB     P1.0          ;DATA = 1
0148 02014D  374      JMP      OTSL1
014B C290    375 BITLS: CLR      P1.0          ;DATA = 0
014D D291    376 OTSL1: SETB     P1.1          ;CLOCK HI
014F 00      377      NOP                      ;NOTE 1
0150 00      378      NOP
0151 00      379      NOP
0152 00      380      NOP                      ;NOTE 2
0153 00      381      NOP
0154 C291    382      CLR      P1.1          ;CLOCK LOW
0156 DAEB    383      DJNZ    R2,OTSLP        ;DECREMENT COUNTER
0158 D290    384      SETB     P1.0          ;TURN PIN INTO INPUT
015A 00      385      NOP                      ;NOTE 1
015B 00      386      NOP                      ;NOTE 2
015C 00      387      NOP
015D D291    388      SETB     P1.1          ;CLOCK ACK
015F 00      389      NOP                      ;NOTE 1
0160 00      390      NOP
0161 00      391      NOP
0162 00      392      NOP                      ;NOTE 2
0163 00      393      NOP
0164 C291    394      CLR      P1.1

```

AN614

```
0166 22      395 RET
              396
              397 ;*****
              398 ; THIS ROUTINE SENDS OUT CONTENTS OF ACCUMLATOR TO EEPROM
              399 ; without sending a START condition.
              400 ;*****
              401
0167 7A08     402 OUT:      MOV      R2,#8          ;LOOP COUNT -- EQUAL TO BIT COUNT
0169 33       403 OTLP:     RLC      A              ;SHIFT BIT
016A 5005     404          JNC      BITL
016C D290     405          SETB     P1.0          ;DATA = 1
016E 020173   406          JMP      OTL1          ;CONTINUE
0171 C290     407 BITL:     CLR      P1.0          ;DATA = 0
0173 D291     408 OTL1:     SETB     P1.1          ;CLOCK HI
0175 00       409          NOP
0176 00       410          NOP
0177 00       411          NOP
0178 00       412          NOP          ;NOTE 2
0179 00       413          NOP
017A C291     414          CLR      P1.1          ;CLOCK LOW
017C DAEB     415          DJNZ     R2,OTLP        ;DECREMENT COUNTER
017E D290     416          SETB     P1.0          ;TURN PIN INTO INPUT
0180 00       417          NOP          ;NOTE 1
0181 00       418          NOP          ;NOTE 2
0182 00       419          NOP
0183 D291     420          SETB     P1.1          ;CLOCK ACK
0185 00       421          NOP          ;NOTE 1
0186 00       422          NOP
0187 00       423          NOP
0188 00       424          NOP          ;NOTE 2
0189 00       425          NOP
018A C291     426          CLR      P1.1
018C 22      427          RET
              428
              429 ;*****
              430 ; THIS ROUTINE READS IN A BYTE FROM THE EEPROM
              431 ; and stores it in the accumulator
              432 ;*****
              433
018D 7A08     434 IN:      MOV      R2,#8          ;LOOP COUNT
018F D290     435          SETB     P1.0          ;SET DATA BIT HIGH FOR INPUT
0191 C291     436 INLP:    CLR      P1.1          ;CLOCK LOW
0193 00       437          NOP          ;NOTE 1
0194 00       438          NOP
0195 00       439          NOP
0196 00       440          NOP
0197 00       441          NOP          ;NOTE 2
0198 00       442          NOP
0199 D291     443          SETB     P1.1          ;CLOCK HIGH
019B C3       444          CLR      C              ;CLEAR CARRY
019C 309001   445          JNB     P1.0,INL1        ;JUMP IF DATA = 0
019F B3       446          CPL      C              ;SET CARRY IF DATA = 1
01A0 33       447 INL1:    RLC      A              ;ROTATE DATA INTO ACCUMULATOR
01A1 DAEE     448          DJNZ     R2,INLP        ;DECREMENT COUNTER
01A3 C291     449          CLR      P1.1          ;CLOCK LOW
01A5 22      450          RET
              451
              452
01A6 C290     453 STOP:    CLR      P1.0          ;STOP CONDITION SET DATA LOW
01A8 00       454          NOP          ;NOTE 1
01A9 00       455          NOP
01AA 00       456          NOP
01AB 00       457          NOP          ;NOTE 2
01AC 00       458          NOP
01AD D291     459          SETB     P1.1          ;SET CLOCK HI
01AF 00       460          NOP          ;NOTE 1
```



```

01B0 00      461          NOP
01B1 00      462          NOP
01B2 00      463          NOP                ;NOTE 2
01B3 00      464          NOP
01B4 D290    465          SETB    P1.0        ;SET DATA HIGH
01B6 22      466          RET
467
468 ;*****
469 ; These routines contain special commands for the 24LC65 SMART SERIAL
470 ; EEPROM
471 ; SET SECURE BLOCK ASSUMES
472 ; START BLOCK 0 & BLOCK LENGTH OF 1. The
473 ; numbers are implicit in the commands.
474 ; Refer to the data sheet for details.
475 ;*
01B7 7B80    476 SETSEC:  MOV    R3,#80H        ;SEND COMMAND AND STARTING BLOCK NUMBER
01B9 7C00    477          MOV    R4,#0          ;
01BB 7981    478          MOV    R1,#81H        ;COMMAND FOR NUMBER OF BLOCKS TO SECURE
01BD 1137    479          CALL   BYTEW        ;EXECUTE
01BF 22      480          RET
481
482 ;*
483 ; READ SECURE BLOCK NUBER(S)
484 ; RETURNS BLOCK NUMBER IN R1 AND BLOCKCOUNT IN R2
485 ; (UPPER NIBBLES WILL BE 1'S)
486 ;*
487
01C0 74A0    488 RDSEC:  MOV    A,#WTCMD        ;LOAD WRITE COMMAND TO SEND ADDRESS
01C2 312F    489          CALL   OUTS        ;SEND IT
01C4 7480    490          MOV    A,#80H        ;LOAD COMMAND
01C6 3167    491          CALL   OUT        ;SEND IT
01C8 7400    492          MOV    A,#0          ;LOAD COMMAND
01CA 3167    493          CALL   OUT        ;SEND IT
01CC 74C0    494          MOV    A,#0C0H        ;LOAD COMMAND
01CE 3167    495          CALL   OUT        ;SEND IT
01D0 318D    496          CALL   IN        ;READ STARTING BLOCK NUMBER
01D2 F9      497          MOV    R1,A          ;STORE IT
01D3 00      498          NOP                ;NOTE 1
01D4 00      499          NOP
01D5 00      500          NOP
01D6 00      501          NOP                ;NOTE 2
01D7 00      502          NOP
01D8 C290    503          CLR    P1.0        ;ISSUE ACK
01DA D291    504          SETB   P1.1
01DC 00      505          NOP                ;NOTE 1
01DD 00      506          NOP
01DE 00      507          NOP
01DF 00      508          NOP                ;NOTE 2
01E0 00      509          NOP
01E1 C291    510          CLR    P1.1
01E3 318D    511          CALL   IN        ;READ NUMBER OF BLOCKS
01E5 FA      512          MOV    R2,A          ;STORE IT
01E6 31A6    513          CALL   STOP        ;SEND STOP CONDITION
01E8 22      514          RET
515
516
517 ;*
518 ; SET HIGH-ENDURANCE BLCOK NUMBER
519 ; ASSUMES BLOCK 0
520 ;*
01E9 7B80    521 SETHI:  MOV    R3,#080H        ;LOAD COMMAND AND BLOCK NUMBER
01EB 7C00    522          MOV    R4,#0
01ED 7900    523          MOV    R1,#0        ;SET DATA = 0
01EF 1137    524          CALL   BYTEW        ;EXECUTE
01F1 22      525          RET
526

```

AN614

```
527 ;*
528 ; READ HIGH ENDURANCE BLOCK NUMBER
529 ; RETURNS BLOCK NUMBER IN R1 (UPPER NIBBLE WILL BE 1'S)
530 ;*
01F2 7B80 531 READHI:      MOV     R3,#080H      ;LOAD COMMAND
01F4 7C00 532              MOV     R4,#0
01F6 1201FA 533          CALL    HIEND        ;EXECUTE
01F9 22    534          RET
535
01FA 74A0 536 HIEND:      MOV     A,#WTCMD      ;LOAD WRITE COMMAND TO SEND ADDRESS
01FC 312F 537          CALL    OUTS        ;SEND IT
01FE EB    538          MOV     A,R3        ;GET HI BYTE ADDRESS
01FF 3167 539          CALL    OUT        ;SEND IT
0201 EC    540          MOV     A,R4        ;GET LOW BYTE ADDRESS
0202 3167 541          CALL    OUT        ;SEND IT
0204 7440 542          MOV     A,#RDEND      ;LOAD READ COMMAND
0206 3167 543          CALL    OUT        ;SEND IT
0208 318D 544          CALL    IN        ;READ DATA
020A F9    545          MOV     R1,A        ;STORE DATA
020B 31A6 546          CALL    STOP       ;SEND STOP CONDITION
020D 22    547          RET
548
549 ;END of 24LC65 Routines
550 ;*****
551 END
552
```

VERSION 1.2h ASSEMBLY COMPLETE, 0 ERRORS FOUND

NOTES:



WORLDWIDE SALES AND SERVICE

AMERICAS

Corporate Office

Microchip Technology Inc.
2355 West Chandler Blvd.
Chandler, AZ 85224-6199
Tel: 480-786-7200 Fax: 480-786-7277
Technical Support: 480-786-7627
Web Address: <http://www.microchip.com>

Atlanta

Microchip Technology Inc.
500 Sugar Mill Road, Suite 200B
Atlanta, GA 30350
Tel: 770-640-0034 Fax: 770-640-0307

Boston

Microchip Technology Inc.
5 Mount Royal Avenue
Marlborough, MA 01752
Tel: 508-480-9990 Fax: 508-480-8575

Chicago

Microchip Technology Inc.
333 Pierce Road, Suite 180
Itasca, IL 60143
Tel: 630-285-0071 Fax: 630-285-0075

Dallas

Microchip Technology Inc.
4570 Westgrove Drive, Suite 160
Addison, TX 75248
Tel: 972-818-7423 Fax: 972-818-2924

Dayton

Microchip Technology Inc.
Two Prestige Place, Suite 150
Miamisburg, OH 45342
Tel: 937-291-1654 Fax: 937-291-9175

Detroit

Microchip Technology Inc.
Tri-Atria Office Building
32255 Northwestern Highway, Suite 190
Farmington Hills, MI 48334
Tel: 248-538-2250 Fax: 248-538-2260

Los Angeles

Microchip Technology Inc.
18201 Von Karman, Suite 1090
Irvine, CA 92612
Tel: 949-263-1888 Fax: 949-263-1338

New York

Microchip Technology Inc.
150 Motor Parkway, Suite 202
Hauppauge, NY 11788
Tel: 631-273-5305 Fax: 631-273-5335

San Jose

Microchip Technology Inc.
2107 North First Street, Suite 590
San Jose, CA 95131
Tel: 408-436-7950 Fax: 408-436-7955

AMERICAS (continued)

Toronto

Microchip Technology Inc.
5925 Airport Road, Suite 200
Mississauga, Ontario L4V 1W1, Canada
Tel: 905-405-6279 Fax: 905-405-6253

ASIA/PACIFIC

Hong Kong

Microchip Asia Pacific
Unit 2101, Tower 2
Metroplaza
223 Hing Fong Road
Kwai Fong, N.T., Hong Kong
Tel: 852-2-401-1200 Fax: 852-2-401-3431

Beijing

Microchip Technology, Beijing
Unit 915, 6 Chaoyangmen Bei Dajie
Dong Erhuan Road, Dongcheng District
New China Hong Kong Manhattan Building
Beijing 100027 PRC
Tel: 86-10-85282100 Fax: 86-10-85282104

India

Microchip Technology Inc.
India Liaison Office
No. 6, Legacy, Convent Road
Bangalore 560 025, India
Tel: 91-80-229-0061 Fax: 91-80-229-0062

Japan

Microchip Technology Intl. Inc.
Benex S-1 6F
3-18-20, Shinyokohama
Kohoku-Ku, Yokohama-shi
Kanagawa 222-0033 Japan
Tel: 81-45-471-6166 Fax: 81-45-471-6122

Korea

Microchip Technology Korea
168-1, Youngbo Bldg. 3 Floor
Samsung-Dong, Kangnam-Ku
Seoul, Korea
Tel: 82-2-554-7200 Fax: 82-2-558-5934

Shanghai

Microchip Technology
RM 406 Shanghai Golden Bridge Bldg.
2077 Yan'an Road West, Hong Qiao District
Shanghai, PRC 200335
Tel: 86-21-6275-5700 Fax: 86 21-6275-5060

ASIA/PACIFIC (continued)

Singapore

Microchip Technology Singapore Pte Ltd.
200 Middle Road
#07-02 Prime Centre
Singapore 188980
Tel: 65-334-8870 Fax: 65-334-8850

Taiwan, R.O.C

Microchip Technology Taiwan
10F-1C 207
Tung Hua North Road
Taipei, Taiwan, ROC
Tel: 886-2-2717-7175 Fax: 886-2-2545-0139

EUROPE

United Kingdom

Arizona Microchip Technology Ltd.
505 Eskdale Road
Wokingham
Berkshire, England RG41 5TU
Tel: 44 118 921 5858 Fax: 44-118 921-5835

Denmark

Microchip Technology Denmark ApS
Regus Business Centre
Lautrup hof 1-3
Ballerup DK-2750 Denmark
Tel: 45 4420 9895 Fax: 45 4420 9910

France

Arizona Microchip Technology SARL
Parc d'Activite du Moulin de Massy
43 Rue du Saule Trapu
Batiment A - 1er Etage
91300 Massy, France
Tel: 33-1-69-53-63-20 Fax: 33-1-69-30-90-79

Germany

Arizona Microchip Technology GmbH
Gustav-Heinemann-Ring 125
D-81739 München, Germany
Tel: 49-89-627-144 0 Fax: 49-89-627-144-44

Italy

Arizona Microchip Technology SRL
Centro Direzionale Colleoni
Palazzo Taurus 1 V. Le Colleoni 1
20041 Agrate Brianza
Milan, Italy
Tel: 39-039-65791-1 Fax: 39-039-6899883

11/15/99



Microchip received QS-9000 quality system certification for its worldwide headquarters, design and water fabrication facilities in Chandler and Tempe, Arizona in July 1999. The Company's quality system processes and procedures are QS-9000 compliant for its PICmicro® 8-bit MCUs, KEELOC® code hopping devices, Serial EEPROMs and microperipheral products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001 certified.

All rights reserved. © 1999 Microchip Technology Incorporated. Printed in the USA. 11/99 Printed on recycled paper.

Information contained in this publication regarding device applications and the like is intended for suggestion only and may be superseded by updates. No representation or warranty is given and no liability is assumed by Microchip Technology Incorporated with respect to the accuracy or use of such information, or infringement of patents or other intellectual property rights arising from such use or otherwise. Use of Microchip's products as critical components in life support systems is not authorized except with express written approval by Microchip. No licenses are conveyed, implicitly or otherwise, under any intellectual property rights. The Microchip logo and name are registered trademarks of Microchip Technology Inc. in the U.S.A. and other countries. All rights reserved. All other trademarks mentioned herein are the property of their respective companies.